






KAMA READER2 取り扱い説明書



- ①xD Picture Card, Smart Media
- ②Compact Flash, Micro Drive
- ③SD Card, SDHC Card, Mini SD, Mini SDHC, Multi Media Card(MMC), RS-MMC(要アダプタ), MMC Micro(要アダプタ)
- ④Memory Stick(PRO, ROM), Memory Stick(DUO, PRO-DUO)
- ⑤Micro SD, Micro SDHC
- ⑥Memory Stick Micro
- ⑦パワー、アクセスLED
(パワーLED→緑色、アクセスLED→赤色、アクセス時は点滅)
- ⑧パワーコネクタ

※同系統のメディアを一緒に読み込むことは出来ません。([例]SDカード使用時にmicroSDカード使用等)

内蔵時のUSBケーブル接続方法



マザーボード
USBコネクタへ



お使いのマザーボードの種類によっては、ピンの向きやピンサインの表記が異なる場合があります。
図を参照にして接続してください。
※ケーブルを逆向きに挿しますと、故障や発火の恐れがありますのでお気を付けてください。

※前面の緑色のパワーLEDにつきましては、接続されているUSBコネクタより電力が供給されている限り点灯するものとなります。
パソコンをシャットダウンされた状態でも、電源自体は+5VSBというスタンバイ用の電圧が出力されているものとなるのですが、環境によりましては、+5Vでの動作をする各機器に対しまして、シャットダウン後もその+5VSBの電圧が出力され続けるものがございます。
その結果シャットダウン後もLEDが点灯し続ける場合がございます。
こちらはマザーボード側のBIOSまたはジャンパーピン設定により、シャットダウン後の+5VSBの電圧出力設定が変更出来る場合がございますので、シャットダウン後もLEDが点灯している状態で、消灯されたいとお考えの方は、お手数ですが一度マザーボードメーカー様まで上記の件をお問い合わせ頂きますよう、お願い申し上げます。

※メディアの挿入方向に関しては、パッケージの側面に記入しておりますので、そちらをご参照ください。
またメディアを逆向きや強く挿したりしますと、KAMA READER2本体やメディア等の破損や故障の原因になりますので、パッケージ側面の図を参照して挿入してください。



Kama Reader 2 Installation Guide




- ①xD Picture Card, Smart Media
- ②Compact Flash, Micro Drive
- ③SD Card, SDHC Card, Mini SD, Mini SDHC, Multi Media Card(MMC), RS-MMC(Requires Adapter), MMC Micro(Requires Adapter)
- ④Memory Stick(PRO, ROM), Memory Stick(DUO, PRO-DUO)
- ⑤Micro SD, Micro SDHC
- ⑥Memory Stick Micro
- ⑦PowerAccess LED
(Power LED: Green, Access LED: Red, Access in Progress: Blinking in Red)
- ⑧Power Connector

※It is not possible to connect the same kind of media simultaneously.
Example: Connecting SD Card and microSD Card

※Green LED light will turn on when the power is taken from USB connector. When the PC is off, the stand-by voltage (+5VSB) can continuously supply the power and the green LED light will remain on. If you wish to turn off this green LED light after the power is off, BIOS or jumper pin settings on your motherboard may enable it. Please contact your motherboard manufacturer for further details on how to disable this stand-by voltage (+5VSB).

※Direction to insert the media, please refer to the package. Please do not insert the media in wrong direction as it can cause damages to your media or this product.

How to Connect USB Cable (Internal)



To motherboard USB Connector

Depending on the motherboard, direction of the pin or assignment maybe different. Please refer to the above image to properly connect the cable.
※Improper connection can cause damages to this product or possible fire.

To Kama Reader 2